Knob installation on Harken HighTailer Winch (IN171)





Place knob on the star drive and tighten the M8 to 2Nm (18 in lb).

Do NOT use Loctite.



Check that the knob opens the self-tailing jaws, by rotating and releasing the knob. The upper jaw should lift during rotation.



Verify that the cover can move up and down freely.